



# INSTALLATION & OPERATION MANUAL



# COMMAND-i

COMMERCIAL HOT WATER & SPACE HEAT PUMP



## Contents

1. Introduction .....	2
2. Dimensions .....	3
3. Safety Instructions .....	4
4. Installation.....	5
4.1 System Installation .....	5
4.2 Location of Installation .....	5
4.3 Airflow Clearances .....	5
4.4 Plumbing .....	6
4.5 Hot Water Circuit Diagram .....	6
4.6 Heating (Cooling) Water Circuit Diagram .....	6
4.7 Electrical Connection .....	6
4.8 Cable & Switch.....	7
4.9 Initial Start-Up .....	7
5. Operation .....	8
5.1 The Controller .....	8
5.2 Operating Functions.....	8
5.2.1 On/Off.....	8
5.2.2 Mode Selection.....	8
5.2.3 Setting the Target Temperature .....	8
5.2.4 Locking the Screen.....	8
5.2.5 Setting a Timer .....	9
5.2.6 Settings.....	9
6. Troubleshooting .....	12
7. Appendix.....	15
7.1 Wiring Diagrams.....	15
7.2 Cable Specifications.....	18
8. Maintenance .....	19
8.1 F.A.Q.....	19
9. Warranty .....	20

## 1. Introduction

This manual contains information relating to the installation, troubleshooting, operation, and maintenance of this EvoHeat unit. Instructions in this manual must always be followed. Failure to comply with these recommendations will invalidate the warranty. Should you have any questions or require technical support, call the EvoHeat office on 1300 859 933 to speak to our team.

The data and information contained in this manual is correct at the time of publishing and is subject to change without notice. For the most up to date manual, contact EvoHeat directly.



Designed with the latest inverter technology, the Evo Command-i is the smarter choice for commercial space and water heating and cooling.


The Evo Command-i Series is ideal for commercial and industrial water and space heating applications, including: hotels, resort, commercial buildings, sporting and leisure facilities, industrial liquid heating and chilling applications.

TECHNICAL DATA		Command-i 40	Command-i 90	Command-i 210
Hot Water Capacity	kW	40	90	210
Water Outlet	L/h	860	1930	4503
Heating Input Power	kW	8.5	19.70	45.7
<b>C.O.P</b>	<b>/</b>	<b>4.7</b>	<b>4.57</b>	<b>4.6</b>
<b>Building Heating A</b>	<b>kW</b>	<b>13~45</b>	<b>16~95</b>	<b>74.8~215</b>
Heating Input Power	kW	4.7~15.3	9.5~28.9	18.8~75.4
<b>C.O.P</b>	<b>/</b>	<b>2.3</b>	<b>2.43</b>	<b>2.42</b>
<b>Building Cooling</b>	<b>kW</b>	<b>9.4~33</b>	<b>20~74.3</b>	<b>46.6~132</b>
Cooling Input Power	kW	3.9~15.8	8.70~25.65	16.5~56.2
<b>EER</b>	<b>/</b>	<b>2.02~2.73</b>	<b>2.52~2.95</b>	<b>2.35~2.82</b>
Heating IPLV	/	3.25	3.2	
Power Supply	/	380-415/3/50	380-415/3/50	380-415/3/50
Max Input Current	A	36.8	51	135
Water Connection	/	DN40	DN65	DN80
Water Flow	L/min	115	172	367
Water Pressure Drop	kPa	75	70	100
Noise	dB(A)	56~65	56~69	63~72
Net Weight	kg	468	733	1140
Dimensions (L/W/H)	mm	1195/980/1900	2170/1150/2130	2481/1331/2367


Hot water conditions: ambient temp. (DB/WB): 20°C/15°C, water circulation is from 15°C to 55°C Building heating A: ambient temp. (DB/WB): 7°C/6°C, water temp (in/out) 40/45°C Building cooling: ambient temp. (DB/WB): 35°C/24°C, water temp (in/out) 12/7°C

**2. Dimensions**


Unit: mm



Command-i	A (L)	B (W)	C (H)	D	E	F	G	H
40	1195	980	1900	925	598	517	516	360



Command-i	A (L)	B (W)	C (H)	D	E	F	G	H
90	2170	1150	2130	1590	1098	614	575	164



Command-i	A (L)	B (W)	C (H)	D	E	F	G	H	I
210	2481	1331	2367	1770	1278	530	360	356	215

### 3. Safety Instructions



Installation, repair, or relocations must only be done by a fully qualified technician. If done incorrectly there is a number of hazards that can occur including fire, electric shock, water leakage and injury.

- When an abnormality (smell of burning, etc.) occurs, stop the unit and disconnect the power or turn off the breaker. If the unit continues to be operated in an abnormal condition, it may cause a fire or hazards.
- Do not insert fingers or objects into the fans or evaporator of the unit.
- Installation, repair or relocations must be done by a fully qualified person and not by the customer. If done incorrectly it may cause fire, electric shock, water leakage and other hazards.
- For unit cleaning or maintenance, switch off and disconnect the power of the unit.
- Do not spray insecticides or flammable sprays around the unit, it may cause a fire or damage the unit's cabinet.
- Do not install the unit near flammable gas or spray flammable substances near it.
- Ensure the heat pump is installed on a strong and stable platform.
- A circuit breaker must be installed for the unit.
- Use supply wires suitable for 75C.
- The heat pump located inside the unit is equipped with an over-load protection system. It does not allow for the unit to start for at least 3 minutes from a previous stoppage.
- Copper or iron must not be used as a fuse. An electrician must use the correct fuse for the heat pump.
- Make sure that the unit and power connection have good earthing.
- If the supply cord is damaged, it must be replaced by the manufacturer, our service agent or a similarly qualified person in order to avoid a hazard.
- Caution: Single wall heat exchanger, not suitable for potable water connection.



## WARNING

### THIS PRODUCT CONTAINS A BUTTON BATTERY

If swallowed, a lithium button battery can cause severe or fatal injuries within 2 hours.

Keep batteries out of reach of children.

If you think batteries may have been swallowed or placed inside any part of the body, seek immediate medical attention.

## 4. Installation

### 4.1 System Installation

When transporting the unit ensure that it is kept upright, lying the unit down may damage inner parts of the unit.



Upon receiving the unit, check the packaging for any obvious signs of damage. Inform EvoHeat immediately if there is any evidence of rough handling.

### 4.2 Location of Installation

The heat pump can be installed onto the concrete basement by using expansion screws, or onto a steel frame with rubber feet which can be placed on the ground or the roof. Ensure that the unit is placed horizontally.

- The unit can be installed in any place outdoors which will be able to support the weight of a heavy unit such as a terrace, roof, the ground and any other places deemed suitable.
- The location must have good ventilation.
- The location must be free from heat radiation and other fire hazards.
- A pall is needed in winter to protect the unit from snow.
- There must be no obstacles near the inlet and outlet of the unit.
- The installation location must be protected from strong winds or air.
- There must be a water channel around the heat pump to drain condensing water.
- Leave enough space around the unit for maintenance.

### 4.3 Airflow Clearances



#### Note:


- Do not cover the air outlet of the unit.
- If there is a barrier above the unit, keep it at least 3000mm above the unit.
- If there are objects stacked around the unit, their height should be at least 400mm lower than the top of the unit.
- When installed in a small room, measures should be taken to prevent leakage of the refrigerant. Once leakage volume exceeds the limit concentration, it may cause suffocation. Contact EvoHeat for specific measures.

### 4.4 Plumbing


When the water pipe is connected:

- Try to reduce the resistance to the water from the piping.
- The piping must be clear and free from dirt and blockage. A water leakage test must be carried out to ensure that there is no water leaking before the installation can be made.
- The pipe must be tested by pressure separately. DO NOT test it together with the unit.
- There must be an expansion tank on the top point of the water loop, and the water level inside the tank must be at least 0.5meters higher than the top point of the water loop.
- The flow switch is installed inside of the heat pump, check to ensure that the wiring and action of the switch is normal and controlled by the controller.
- Try to avoid any air from being trapped inside the water pipe, there must be an air vent on the top point of the water loop.
- There must be a thermometer and pressure meter at the water inlet and outlet for easy inspection during running.

### 4.5 Hot Water Circuit Diagram



### 4.6 Heating (Cooling) Water Circuit Diagram



	Flexible Pipe		Gate Valve		Check Valve		Level Controller		Differential pressure bypass valve
	Pressure Gauge		Shut-off Valve		Thermometer (0-100)		Electric two-way valve		
	Water Valve		Solenoid Valve		Y Type Water filter		Water flow Switch		

### 4.7 Electrical Connection




Always use a suitably qualified Electrician to perform any electrical work, they must read the manual before connecting.

Ensure all cabling, circuit breakers, and protections are of a suitable size and specification in accordance with electrical wiring legislation for the heater being installed. Ensure to check that there is adequate voltage and current available at the heater connection to run the unit.

- Open the front panel and open the power supply access.
- The power supply must go through the wire access and be connected to the power supply terminals in the controlling box. Then connect the 3-signal wire plugs of the wire controller and main controller.
- If an external water pump is required, please insert the power supply wire into the wire access and connect it to the water pump terminals.
- If an additional auxiliary heater is needed to be controlled by the heat pump controller, the relay (or power) of the aux-heater must be connected to the relevant output of the controller.

## 4.8 Cable & Switch



- The unit should use an independent power supply, wiring as required for Table 6.1. Power supply voltage must be in line with the rated voltage.
- Power supply circuit must be equipped with an All-pole disconnect device and have at least 3mm contact opening distance.
- Wiring is only to be performed with a professional technician in accordance with the circuit diagram.
- The Power supply circuit must have an earth wire. The earth wire of the power should be connected with the external earth wire safely. The external earth wire must be in order correctly.

## 4.9 Initial Start-Up

### Pre-Inspection

- Check the indoor unit, make sure that the pipe connection is done correctly, and the relevant valves are open.
- Check the water loop to ensure that the water inside of the expansion tank is filled to an appropriate level, and the water supply is working, and the water loop is full of water and free of trapped air. Make sure there is good insulation for the water pipe.
- Check the electrical wiring. Make sure that the power voltage is normal, the screws are fastened, the wiring is made in line with the diagram and that the earthing is connected.
- Check that the heat pump includes all the screws and components, and that they are in good order. When powering the unit on, review the indicator on the controller to see if there is any indication of failure. The gas gauge can be connected to the check valve to see the high pressure (or low pressure) of the system during trial running.


### Trial Running

- Start the heat pump by pressing the 'POWER' button on the controller. Check whether the water pump is running, if it runs normally there will be 0.2MPa on the water pressure meter.
- When the water pump has ran for a minute, the compressor will start. Listen for any strange sounds from the compressor, if an abnormal sound occurs please stop the unit and check the compressor. If the compressor runs well, look for the pressure meter of the refrigerant.
- Check whether the power input and running current is in line with the manual. If not, stop and check.
- Adjust the valves on the water loop to make sure that the hot (cool) water supply to each door is good and meets the requirements of heating (or cooling).
- Review whether the outlet water temperature is stable.
- The parameters of the controller are set by the factory, the user must change these themselves.




## 5. Operation

### 5.1 The Controller



<b>Power</b>	Turn the unit on or off
<b>Setpoint</b>	Set the target temperature
<b>Mode</b>	Select heating or cooling mode
<b>Lock</b>	Lock or unlock the screen
<b>Timer</b>	Enter timer setting menu (Temp Timer, Power Timer & Mute Timer)
<b>Setting</b>	Enter function menu (Status, Parameter, Failures & Time)
Inlet Setpoint:	Target temperature of inlet water
11 FEB 2019 13:03 MON	Unit's set date & time
<b>Display Circle</b>	Blue: Cooling mode, Red: Heating Mode, Grey: Off

Icons will appear at the top right of the screen indicating certain functions that are enabled, or if there has been an error with the system.



### 5.2 Operating Functions

#### 5.2.1 On/Off

From the main menu, simply press the '**Power**' button to turn the unit on or off.

#### 5.2.2 Mode Selection

From the main menu, pressing the '**Mode**' button will allow you to select either heating or cooling mode. The status bar (bottom of the screen) will display the unit's current operating state.

The display circle will appear as red for heating, or blue for cooling. If the unit is off, it will simply be grey.

#### 5.2.3 Setting the Target Temperature

To adjust the target temperature value, first choose a running mode (heating or cooling), then press the '**Setpoint**' button to enter the parameter setting screen.

Enter the required parameter according to the effective range which is displayed at the bottom of the screen.


#### 5.2.4 Locking the Screen

From the main menu, press the '**Lock**' button to lock the controller screen and prevent unauthorised people accessing the controls.

When the screen is locked a small lock symbol will appear on the top right of the main menu.

To unlock the screen, press the '**Lock**' button again and enter the password **22** which will unlock the screen and remove the lock symbol.

**5.2.5 Setting a Timer**



After pressing the 'Timer' button from the main interface, select from Temp Timer or Power Timer.

**5.2.5.1 Temperature Timers**

This function enabled time-sharing temperature control, which is two segments of staggered peak temperature control, and allows the target temperature of two segments of different time periods to be set according to different modes.

Press (23) to select from cooling: or heating mode, then enter the start time, ending time and the target temperature setpoint value (24). Press (25) to enable or disable the settings.

**5.2.5.2 Power Timer**

This function allows you to set the opening time of the unit for each day of the week.


Press (26) to select the day of the week, then (27) to select AM or PM, after this press (28) to select the time, and finally select (29) to enable or turn off the setting.

**5.2.5.3 Mute Timer**

From the Timer menu, then press the Mute Timer button. Enter the start and end for the timer, then press the on/off button to enable or disable the function. When this function is enabled, a mute icon will appear on the main screen.

Note\*: If the unit does not have the mute timer option, the function is not available.

**5.2.6 Settings**



After pressing the 'Setting' button on the main menu, you can select from a range of functions.

**5.2.6.1 Status**


Press Status (30) to choose from Running Status or Unit Status.

**Running Status**

See below image.

**Unit Status**

Enter the password **22** to inquire the unit status parameter. Press one of the 4 buttons to inquire relevant parameters.



Running Status Screen



Unit Status Screen

### 5.2.6.2 Parameters

After pressing the parameter button (31) from the settings menu, enter the password **22** to jump to the Installer Parameter interface for inquiring about relevant parameters.




### 5.2.6.3 Failure

When a failure is present, the red failure alarm will be flashing on the main menu. First press '**Settings**' then '**Failure**' to view the failure records.

Once maintenance has been completed, press the 'clear' button to delete the failure history.

### 5.2.6.4 Time

To change the system's date & time, click on the input field and enter the correct values. Press 'save' in the top right corner to save the settings.




### 5.2.6.5 Temperature Curve

Press (34) to view the inlet/outlet temperature curve.

- This curve function records the water inlet outlet temperature.
- Temperature data is collected every 5 minutes, and the 12 sets of temperature data are saved every hour. Timekeeping is made from the latest data saving. If the power is disrupted before all 12 data sets have been collected the data will not be saved.
- Only curve for the electricity status is recorded, the outage status will not be saved.
- The value of the abscissa indicates the time from the point on the curve to the current time point. The leftmost point on the first page (0 on the abscissa is the latest temperature record).
- Temperature curve record is provided with power off memory function; in the case of a disturbed curve recording and display, when the unit is next powered on the wire controller will automatically clear the history curve record and the curve recording function will restore to a normal state.

### 5.2.6.6 Electric Heating

In the settings menu, the Electric Heating option will display as 'OFF Electric Heating'. Make sure that the unit is firstly in heating mode, then press the electric heating button to head to its interface. Click the button to turn it on to activate the electric auxiliary heating mode. Turn off the function by tapping the button again.



### 5.2.6.7 Fast Mute

The button will initially display as 'OFF Fast Mute' or 'ON Fast Mute'. Press the button to enable/disable this function.


### 5.2.6.8 Display Calibration

Enter the Unit status menu in the following order (see 5.7.1 Status for password):

Main Interface → Setting → Status → Unit Status

Click the screen in the bottom left corner over 10 times within 4 seconds to bring up the display calibration interface. Click the blank squares to check whether there are bad spots within the screen. Green spots are normal.

To exit, click the screen in the bottom right corner.



## 6. Troubleshooting

Protect/Fault	Fault Display	Reason	Elimination Methods
Communication Fault	E08	Abnormal communication between wire controller and the main board	Inspect whether the wire controller, the main board and the connection thereof are reliable
The Wire Controller Does Not Match The Mainboard	E084		
DC Fan Board 1 Communication Fault	E081	Communication of the speed regulation module 1 with main board is abnormal	"Check the speed regulation module 1 and the main board and if their connections are normal and reliable."
Syst1: High Pressure Prot.	E11	The high-voltage switch of the system is disconnected	Inspect System 1 voltage switch and refrigerating circuit for any failure
Syst2: High Pressure Prot.	E21	The high-voltage switch of the system is disconnected	Inspect System 2 voltage switch and refrigerating circuit for any failure
Syst1: Low Pressure Prot.	E12	The low-voltage switch of the system is disconnected	Inspect System 1 voltage switch and refrigerating circuit for any failure
Syst2: Low Pressure Prot.	E22	The low-voltage switch of the system is disconnected	Inspect System 2 voltage switch and refrigerating circuit for any failure
Water Flow Switch Prot.	E032	The water system has no or only few water	Inspect whether the water flow of the water pipe conforms to related requirements and check the water pump for any damages
Electric Heater Overload Prot.	E04	Electric heating overheat protection switch is disconnected	Inspect whether the electric heating is under operation condition of over 150°C for a long time
Primary Antifreezing Prot. In Winter	E19	Excessively low environment temperature	
Secondary Antifreezing Prot. in Winter	E29	Excessively low environment temperature	
Syst1: User Side Antifreezing Prot.	E171	The water flow of the system is insufficient	Inspect whether the water flow of the water pipe conforms to related requirements and check the water pump for any blockage
Syst2: User Side Antifreezing Prot.	E271	The water flow of the system is insufficient	Inspect whether the water flow of the water pipe conforms to related requirements and check the water pump for any blockage
Water(Out) High Temp Prot.	E065	Excessively high water outlet temperature	
Fan 1 Thermal Overload Prot.	E103	Fan 1 thermal overload	Check if fan 1 is running normally
Fan 2 Thermal Overload Prot.	E203	Fan 2 thermal overload	Check if fan 2 is running normally
Syst1: Exhaust Air High Temp Prot.	P182	The system compressor is overloaded	Inspect whether the operation of System 1 compressor is normal
Syst2: Exhaust Air High Temp Prot.	P282	The system compressor is overloaded	Inspect whether the operation of System 2 compressor is normal
Water In/Out Large Temp Diff Prot.	E06	The water flow of the system is insufficient, the pressure difference of the water system is small	Inspect whether the water flow of the water pipe conforms to related requirements and check the water pump for any blockage
Water(Out) Low Temp Prot.	E071	Excessively low water outlet temperature	
Low Water Flow Prot.	E035	The system has no water or too low volume of water	Check if the water flow of water pipe meets the requirements and if the water pump is damaged.
Syst1: Refrigerant Leakage Abnormal	E131	System 1 refrigerant leakage	Check if the refrigerant in the system leaks
Syst2: Refrigerant Leakage Abnormal	E231	System 2 refrigerant leakage	Check if the refrigerant in the system leaks
Syst1: 4-Way Valve Abnormal Switch	E121	SYS1 four-way valve switching failed	Check if the four-way valve commutation state is the desired state
Syst2: 4-Way Valve Abnormal Switch	E221	SYS2 four-way valve switching failed	Check if the four-way valve commutation state is the desired state
Syst1: Low Pressure Prot. 3+	E12	The low-voltage switch of the system is disconnected	Inspect System 1 voltage switch and refrigerating circuit for any failure
Syst2: Low Pressure Prot. 3+	E22	The low-voltage switch of the system is disconnected	Inspect System 2 voltage switch and refrigerating circuit for any failure
Water Flow Switch Prot. 3+	E032	The water system has no or only few water	Inspect whether the water flow of the water pipe conforms to related requirements and check the water pump for any damages
Electric Heater Overload Prot. 3+	E04	Electric heating overheat protection switch is disconnected	Inspect whether the electric heating is under operation condition of over 150°C for a long time
Syst1: User Side Antifreezing Prot. 3+	E171	The water flow of the system is insufficient	Inspect whether the water flow of the water pipe conforms to related requirements and check the water pump for any blockage
Syst2: User Side Antifreezing Prot. 3+	E271	The water flow of the system is insufficient	Inspect whether the water flow of the water pipe conforms to related requirements and check the water pump for any blockage
Water(Out) High Temp Prot. 3+	E065	Excessively high water outlet temperature	


Low Water Flow Prot. 3+	E035	The system has no water or too low volume of water	Check if the water flow of water pipe meets the requirements and if the water pump is damaged.
Syst1: Exhaust Air High Temp Prot. 3+	P182	The system compressor is overloaded	Inspect whether the operation of System 1 compressor is normal
Syst2: Exhaust Air High Temp Prot. 3+	P282	The system compressor is overloaded	Inspect whether the operation of System 2 compressor is normal
Water In/Out Large Temp Diff Prot. 3+	E06	The water flow of the system is insufficient, the pressure difference of the water system is small	Inspect whether the water flow of the water pipe conforms to related requirements and check the water pump for any blockage
Water(Out) Low Temp Prot. 3+	E071	Excessively low water outlet temperature	
Water In Sensor Fault	P01	The temperature sensor is open or short circuited	Check and replace inlet water temperature sensor
Water Out Sensor Fault	P02	The temperature sensor is open or short circuited	Check and replace outlet water temperature sensor
Syst1: Coil Temp Sensor1 Fault	P150	The temperature sensor is open or short circuited	Check and replace the system 1 coil 1 temperature sensor
AT Sensor Fault	P04	The temperature sensor is open or short circuited	Check and replace the ambient temperature sensor
Syst1: Suction Temp Sensor Fault	P17	The temperature sensor is open or short circuited	Check and replace the system 1 return air temperature sensor
Syst1: User Side Antifreezing 1 Sensor Fault	P191	The temperature sensor is open or short circuited	Check and replace the system 1 use side antifreeze 1 temperature sensor
Syst2:Coil Temp Sensor1 Fault	P250	The temperature sensor is open or short circuited	Check and replace the system 2 coil 1 temperature sensor
Syst1: Coil(Out) Temp Sensor Fault	P152	The temperature sensor is open or short circuited	Check and replace the system 1 coil outlet temperature sensor
Syst2: Coil(Out) Temp Sensor Fault	P252	The temperature sensor is open or short circuited	Check and replace the system 2 coil outlet temperature sensor
Syst1: EVI(In) Temp Sensor Fault	P101	The temperature sensor is open or short circuited	Check and replace the system 1 EVI inlet temperature sensor
Syst1: EVI(Out) Temp Sensor Fault	P102	The temperature sensor is open or short circuited	Check and replace the system 1 EVI outlet temperature sensor
Syst1: Exhaust Air Temp Sensor Fault	P181	The temperature sensor is open or short circuited	Check and replace the system 1 exhaust temperature sensor
Water Level Sensor Fault	E036	Open circuit or short circuit of the water level sensor	Inspect and replace water level sensor
Syst1: Low Pressure Sensor Fault	PP11	The sensor is open or short circuited	Check and replace the system 1 low pressure sensor
Syst2: Suction Temp Sensor Fault	P27	The temperature sensor is open or short circuited	Check and replace the system 2 return air temperature sensor
Syst2: User Side Antifreezing 1 Sensor Fault	P291	Temperature sensor fault	Check if the temperature sensor is working properly
Syst1: High Pressure Sensor Fault	PP12	The sensor is open or short circuited	Check and replace the system 1 high pressure sensor
Syst2: High Pressure Sensor Fault	PP22	The sensor is open or short circuited	Check and replace the system 2 high pressure sensor
Syst2: Exhaust Air Temp Sensor Fault	P281	Open circuit or short circuit of the temperature sensor	Inspect and replace System 2 exhaust temperature sensor
Syst2: Low Pressure Sensor Fault	PP21	Open circuit or short circuit of the sensor	Inspect and replace System 2 low-voltage sensor
Water Tank Temp Fault	P03	Open circuit or short circuit of the temperature sensor	Inspect and replace water tank temperature sensor
Syst2: EVI(In) Temp Sensor Fault	P201	Open circuit or short circuit of the temperature sensor	Inspect and replace System 2 enthalpy inlet temperature sensor
Syst2: EVI(Out) Temp Sensor Fault	P202	Open circuit or short circuit of the temperature sensor	Inspect and replace System 2 enthalpy outlet temperature sensor
Low AT Power-Off Prot.	TP	Excessively low environment temperature	
Syst1: Coil Temp Sensor2 Fault	P154	The temperature sensor is open or short circuited	Check and replace the system 1 coil 2 temperature sensor
DC Fan Board 2 Communication Fault	E082	Communication of the speed regulation module 2 with main board is abnormal	Check the speed regulation module 2 and the main board and if their connections are normal and reliable.
Syst2: Coil Temp Sensor2 Fault	P254	The temperature sensor is open or short circuited	Check and replace the system 2 coil 2 temperature sensor
Syst1: Comp. Communication Fault	F151	Communication failure with system 1 compressor drive board	1. Check if the communication line is normal; 2. Check if the system 1 compressor drive board is normal
Syst1: Comp. Start Fault	F152	System 1 compressor failed to start	1. Check if the compressor line is normal; 2. Check if the system 1 compressor is blocked
Syst1: Start IPM Prot.	F153	System 1 compressor starting current is too large	1. Check if the starting high pressure is excessive; 2. Check if the system 1 compressor is blocked

Syst1: Running IPM Prot.	F154	System 1 compressor running current is too large	Check if the pressure ratio is too high
Syst1: Comp. Overcurrent Prot.	F156	System 1 compressor running current is too large	Check if the pressure ratio is too high
Comp. 1 IPM Over-Temp. Prot.	F155	System 1 compressor drive board has poor heat dissipation	Check if there is a gap in the installation of the fluorine-cooled heat sink
Press 1 Bus Over Voltage Prot.	F157	Voltage is too high	Check if the input voltage is higher than 480V
Press 1 Bus Under Voltage Prot.	F158	Voltage is too low	Check if the input voltage is lower than 250V
Syst2: Comp. Communication Fault	F251	Communication failure with system 2 compressor drive board	1. Check if the communication line is normal; 2. Check if the system 2 compressor drive board is normal
Syst2: Comp. Start Fault	F252	System 2 compressor failed to start	1. Check if the compressor line is normal; 2. Check if the system 2 compressor rotor is locked
Syst2: Start IPM Prot.	F253	System 2 compressor starting current is too large	1. Check if the starting high pressure is excessive; 2. Check if the system 1 compressor is blocked
Syst2: Running IPM Prot.	F254	System 2 compressor running current is too large	Check if the pressure ratio is too high
Syst2: Comp. Overcurrent Prot.	F256	System 2 compressor running current is too large	Check if the pressure ratio is too high
Press 2 IPM Over-Temp Prot.	F255	System 2 compressor drive board has poor heat dissipation	Check if there is a gap in the installation of the fluorine-cooled heat sink
Press 2 Bus Over Voltage Prot.	F257	Voltage is too high	Check if the input voltage is higher than 480V
Press 2 Bus Under Voltage Prot.	F258	Voltage is too low	Check if the input voltage is lower than 250V
Fan 1 Phase Loss Prot.	F101	System 1 fan failed to start	Check if the system 1 fan line is normal
Fan 1 Zero Speed Prot.	F102	System 1 fan failed to start	Check if the system 1 fan rotor is locked
Fan 1 Start IPM Prot.	F103	System 1 fan starting current is too large	Check if the system 1 fan rotor is locked
Fan 1 Running IPM Prot.	F104	System 1 fan running current is too large	Check if the system 1 fan rotor is locked
Fan 1 Overcurrent Prot.	F105	System 1 fan running current is too large	Check if the system 1 fan rotor is locked
Fan 1 Over-Temp Prot.	F106	System 1 fan drive board has poor heat dissipation	Check the heat dissipation condition
Fan 1 Bus Over Voltage Prot.	F107	Voltage is too high	Check if the input voltage is higher than 480V
Fan 1 Bus Under Voltage Prot.	F108	Voltage is too low	Check if the input voltage is lower than 250V
Fan 2 Output Phase Loss Prot.	F201	System 2 fan failed to start	Check if the system 2 fan line is normal
Fan 2 Output Zero Speed Prot.	F202	System 2 fan failed to start	Check if the system 2 fan rotor is locked
Fan 2 Start IPM Prot.	F203	System 2 fan starting current is too large	Check if the system 2 fan rotor is locked
Fan 2 Running IPM Prot.	F204	System 2 fan running current is too large	Check if the system 2 fan rotor is locked
Fan 2 Overcurrent Prot.	F205	System 2 fan running current is too large	Check if the system 2 fan rotor is locked
Fan 2 Over-Temp Prot.	F206	System 2 fan drive board has poor heat dissipation	Check the heat dissipation condition
Fan 2 Bus Over Voltage Prot.	F207	Voltage is too high	Check if the input voltage is higher than 480V
Fan 2 Bus Under Voltage Prot.	F208	Voltage is too low	Check if the input voltage is lower than 250V
Abnormal Power Fault	EE1		
Syst1: High Suction Temp Prot.	E077	SYS1 return air temperature is too high	Check if the return air temperature sensor is normal
Syst2: High Suction Temp Prot.	E078	SYS2 return air temperature is too high	Check if the return air temperature value is greater than the protection value
Syst1: High Suction Temp Prot. 3+	E077	SYS1 return air temperature is too high	Check if the return air temperature sensor is normal
Syst2: High Suction Temp Prot. 3+	E078	SYS2 return air temperature is too high	Check if the return air temperature value is greater than the protection value


## 7. Appendix

**Note:** View the PDF version of this manual online to zoom into the wiring diagrams without losing quality.

### 7.1 Wiring Diagrams








Evo Command-i 90

# PC1602

CODE : 727000001871-00

Evo Command-i 210

CODE: 20221009-0002



## 7.2 Cable Specifications

Nameplate maximum current	Phase line (Single Phase)	Phase Line (Three Phase)	Earth line	MCB	Creepage Protector	Signal Line
No more than 10A	2 x 1.5mm <sup>2</sup>	3 x 1.5mm <sup>2</sup>	1.5mm <sup>2</sup>	20A	30mA less than 0.1 sec	n x 0.5mm <sup>2</sup>
10~16A	2 x 2.5mm <sup>2</sup>	3 x 2.5mm <sup>2</sup>	2.5mm <sup>2</sup>	32A		
16~25A	2 x 4mm <sup>2</sup>	3 x 4mm <sup>2</sup>	4mm <sup>2</sup>	40A		
25~32A	2 x 6mm <sup>2</sup>	3 x 6mm <sup>2</sup>	6mm <sup>2</sup>	40A		
32~40A	2 x 10mm <sup>2</sup>	3 x 10mm <sup>2</sup>	10mm <sup>2</sup>	63A		
40~63A	2 x 16mm <sup>2</sup>	3 x 16mm <sup>2</sup>	16mm <sup>2</sup>	80A		
63~75A	2 x 25mm <sup>2</sup>	3 x 25mm <sup>2</sup>	25mm <sup>2</sup>	100A		
75~101A	2 x 25mm <sup>2</sup>	3 x 25mm <sup>2</sup>	25mm <sup>2</sup>	125A		
101~123A	2 x 35mm <sup>2</sup>	3 x 35mm <sup>2</sup>	35mm <sup>2</sup>	160A		
123~148A	2 x 50mm <sup>2</sup>	3 x 50mm <sup>2</sup>	50mm <sup>2</sup>	225A		
148~186A	2 x 70mm <sup>2</sup>	3 x 70mm <sup>2</sup>	70mm <sup>2</sup>	250A		
186~224A	2 x 95mm <sup>2</sup>	3 x 95mm <sup>2</sup>	95mm <sup>2</sup>	280A		

## 8. Maintenance

### 8.1 F.A.Q



#### DO I NEED TO GET MY UNIT SERVICED?

It is recommended that you get your EvoHeat unit serviced once a year by your local certified air conditioning or refrigeration technician. If your unit is located in a coastal area, more frequent maintenance may be necessary. During the service, they will check the operational pressures of the refrigeration system and give the unit and fins a good clean to ensure maximum performance.



#### DO WE HAVE RECOMMENDED SERVICE AGENTS?

EvoHeat have a large database of recommended service agents. Please contact EvoHeat tech support on 1300 859 933 for your local service agent details.



#### SHOULD I CHECK MY UNIT REGULARLY?

We recommend you check your unit regularly to avoid potential issues and damage to your heat pump.

Check the water inlet/outlets often for leaks. You should avoid the condition of no water or air entering into the system, as this will influence unit's performance and reliability.

The area around the unit should be dry, clean and well ventilated. Make sure there is nothing blocking the airflow of the heater e.g. Leaf litter. Clean the heat exchanger every few months to keep a good heat exchange rate and save energy.



#### WHAT SHOULD I BE CHECKING REGULARLY?

You should discharge the water at the bottom of the water pump if the unit will not be used for an extended period. Discharge all water in the water pump and water system so that freezing of the water in the pump or water system does not occur. Check the unit thoroughly and fill the system with water fully before using it for the first time after a period of time.

Check the power supply and cable connection often, should the unit begin to operate abnormally, switch it off and contact the qualified technician

Clean the water filter periodically to maintain good water quality. Lack of water and dirty water can damage the unit. The heat pump will start the water every 72 hours when it is not running to avoid freezing.

The water loop of the heat pump MUST be protected from freezing in winter. Do not shut off the power supply to the heat pump in winter. When the air temperature is below 0°C, if the inlet water temperature is above 2°C and below 4°C the water pump will begin freezing protection. If the inlet water is lower than 2°C, the heat pump will begin heating.

## 9. Warranty



### Refer to the EvoHeat website for warranty details

- Australia: <https://evoheat.com.au/warranty-terms/>
- South East Asia: <http://evoheat.com.sg/warranty/>

1. Warranty terms are from date of purchase.
2. This warranty excludes any defect or injury caused by or resulting from misuse, abuse, neglect, accidental damage, improper voltage, vermin infestation, incompetent installation, any fault not attributable to faulty manufacture or parts, any modifications which affect the reliability or performance of the unit.
3. This warranty does not cover the following:
  - a. Natural Disasters (hail, lightning, flood, fire etc.)
  - b. Rust or damage to paintwork caused by a corrosive atmosphere
  - c. When serviced by an unauthorized person without the permission of Evo Industries
  - d. When a unit is installed by an unqualified person
  - e. Where a unit is incorrectly installed
  - f. When failure occurs due to improper or faulty installation
  - g. Failure due to improper maintenance (refer Operating Instructions)
  - h. 'No Fault Found' service calls where the perceived problem is explained within the
  - i. Costs associated with delivery, handling, freighting, or damage to the product in transit.
4. If warranty service is required, you should:
  - a. contact Evo Industries Australia on 1300 859 933 or via our Contact page on our web site
  - b. provide a copy of your receipt as proof of purchase
  - c. have completed the online *Warranty Registration Form*
5. Onsite technical service is available within the normal operating area of your Evo Authorised Service Agents. Service outside this area will incur a traveling fee.
6. Unless otherwise specified to the purchaser, the benefits conferred by this express warranty and additional to all other conditions, warranties, rights and remedies expressed or implied by the Trade Practices Act 1974 and similar consumer protection provisions contained in legislation of the States and Territories and all other obligations and liabilities on the part of the manufacturer or supplier and nothing contained herein shall restrict or modify such rights, remedies, obligations or liabilities.

**REGISTER YOUR WARRANTY**

EvoHeat highly recommend customers complete their warranty details online to ensure efficient warranty claim processing.

To register your warranty, scan our QR Code or head to our website and fill in the Warranty Registration Form: <https://evoheat.com.au/warranty-registration/>

